



So You Have a Busy Light...

A friendly user guide to your new desktop meeting indicator

LESSARD INDUSTRIES

Welcome! The little device sitting on your desk is a **Busy Light** — a tiny, always-on assistant that lets the people around you (and you yourself) know, at a glance, whether you're in a meeting, available, working remotely, or off the clock. It talks to your Microsoft 365 calendar over the internet and lights up the appropriate color all on its own. No app, no logging in, no fuss.

This guide walks you through what each of the five colored buttons does, what the lights mean during normal operation, and what those blinks and flashes mean when it first powers up. Keep it nearby for the first few days — after that, you probably won't need it.

Meet Your Busy Light

Your Busy Light has **five colored buttons**, each paired with an LED of the same color. From left to right (or top to bottom, depending on how it's mounted), they are:

● Red ● Green ● Blue ● Yellow ○ White

Plug it in to any USB power source. That's the entire installation. It will connect to Wi-Fi, sync its clock, find your calendar, and start showing your status. The next time you have a meeting on your work calendar, the red light will come on by itself.

What the Lights Mean (Normal Use)

During the workday (8:30 AM–4:30 PM, or your business hours if different), one of these will be true:

Light	What it means
● Solid Red	You are in a meeting right now. Do not disturb.
● Pulsing Red (fading in and out)	A meeting is starting in less than one minute . Wrap up that conversation!

 Solid Green	You are free and available. Come on in.
 Solid Blue	It's a remote work day . You aren't at your desk today.
 All lights off	Outside of business hours. The Busy Light goes dark on its own at the end of the workday and stays dark until the next morning (8:30 AM–4:30 PM by default, or whatever business hours were set for your device).

HOW IT KNOWS

Every three minutes the Busy Light quietly checks your calendar in the cloud. When it sees you have a meeting, it turns red. When the meeting ends, it turns green again. Five minutes before a meeting it double-checks early, and one minute before, it pulses red as a heads-up.

What the Buttons Do

Each button has **two behaviors** — a *short press* (tap and release) and a *long press* (hold for about 1.5 seconds). Short presses are your manual overrides, long presses unlock the fun stuff.

Short Press — Manual Override

Tap any colored button to **manually force** that color on. The Busy Light will stop following your calendar and just stay that color until you tell it otherwise. Tap the same button again to turn it off entirely.

Button	Short Press Effect
 Red	Force Red on (manual "busy" — useful when you're on a phone call that isn't on your calendar)
 Green	Force Green on (manual "available")
 Blue	Force Blue on (manual "remote")
 Yellow	Force Yellow on (whatever you'd like it to mean — "back in 5", "headphones on", etc.)
 White	Force White on (good for a quick reading light at your desk)

GETTING BACK TO AUTOMATIC

When you manually pick a color, the Busy Light stops following your calendar. To put it back on autopilot, **press and hold the White button** for about 1.5 seconds. You'll see all lights briefly go off, then a quick white flash — that's your "got it" acknowledgement — and then the Busy Light goes back to matching your calendar.

Long Press — Special Light Modes

Hold any button (other than White) for about 1.5 seconds to unlock a light show. Great for parties, end-of-day demos, or just for fun. Tap any button briefly to exit and return to normal operation.

Hold This Button	What Happens
 Red (hold)	Double Disco — two random LEDs fade in and out together
 Green (hold)	Time Travel — all five LEDs fade independently at different speeds
 Blue (hold)	Color Circle — lights chase smoothly around in a circle
 Yellow (hold)	Disco — one random LED fades in and out at a time
 White (hold)	Resume Automatic Mode — go back to following your calendar

Powering On — What the Startup Lights Mean

When you first plug the Busy Light in (or whenever it reboots — it restarts itself once a day at around 6:55 AM for reliability), it goes through a quick startup sequence. You'll see a series of blinks while it finds its way onto the network. Here's a quick translation guide:

What You See	What's Happening
 Slow green blink	Looking for a known Wi-Fi network and trying to connect.
 Slow yellow blink	Couldn't find a known network — falling back to setup mode.
 Three bursts of three fast yellow blinks	Wi-Fi setup mode is active. The Busy Light has created its own temporary Wi-Fi network so you can configure it (see "First-Time Wi-Fi Setup" below).
 Slow blue blink	Connected to Wi-Fi — syncing the clock with internet time servers.
 Brief white flash	Time is synced. The Busy Light is now ready and will show your calendar status.
 Five fast red blinks	Something went wrong — usually a clock sync problem. The device will retry on its own; if it persists, unplug for 10 seconds and plug back in.

A NOTE ON TIMING

When several Busy Lights power up at the same time (after a power outage, for example), each one waits a random few seconds before starting up so they don't all hit the network at once. Don't be alarmed if yours takes a

few extra seconds to come to life — it's being polite.

First-Time Wi-Fi Setup

If your Busy Light has never been on your network before — or if your Wi-Fi password has changed — it will go into **setup mode** (the yellow blink bursts described above). Here's how to get it connected:

1. On your phone or laptop, go to your Wi-Fi settings.
2. Look for a network named **BusyLight-X-Setup** (or your friendly device name, followed by "Setup") and connect to it.
3. A configuration page should pop up automatically. If not, open a browser and go to **192.168.4.1**.
4. Select your home or office Wi-Fi network from the list and enter the password.
5. Tap Save. The Busy Light will reboot, connect to your network, and start working.

You only have to do this once. After that, it remembers your network and will reconnect automatically every time it's powered on.

Daily Rhythm

Here's what a typical day looks like from the Busy Light's perspective:

- **Before 7:00 AM** — All lights off. Sleeping in.
- **7:00 AM** — Wakes up briefly to check today's schedule (any remote-work flags, etc.). Then dims back down.
- **8:30 AM** (or your start time) — Business hours begin. Lights turn on to show your current status.
- **Throughout the day** — Checks your calendar every three minutes and updates color accordingly.
- **4:30 PM** (or your end time) — Business hours end. Lights turn off until tomorrow.

Troubleshooting

If you see...	Try this
The light is the wrong color (says I'm busy when I'm free, or vice versa)	Press and hold the White button for 1.5 seconds to resume automatic mode — you may have left it in manual override.

No lights at all during the workday	Check the USB power cable. If powered, look for a startup blink sequence. If you only see green or yellow blinks, it's trying to reach the network.
Yellow blink bursts that don't stop	The Busy Light needs Wi-Fi setup. See "First-Time Wi-Fi Setup" above.
It's been red for hours but I'm not actually in a meeting	Hold the White button for 1.5 seconds to resume automatic mode. If still wrong, unplug for 10 seconds and plug back in.
Five fast red blinks on startup	The clock sync failed — usually a temporary network issue. It will retry on its own. If it keeps happening, unplug for 10 seconds and plug back in.

Quick Reference Card

Lights (normal use)	
 Red, solid	In a meeting
 Red, pulsing	Meeting in < 1 minute
 Green	Available
 Blue	Remote day
 Off	Outside business hours
Buttons	
Tap any color	Force that color on (manual override)
Tap same color again	Turn off
Hold White (1.5s)	Resume automatic / calendar mode
Hold Red / Green / Blue / Yellow	Light show modes (any tap exits)

LESSARD INDUSTRIES

Busy Light · Firmware v8.1 · Designed and built in-house

Questions? Find Ed.